



# Ride




1. Push in the battery safety button to turn the power on.  
2. Select the right speed mode based on rider skills (level three being the fastest).



3. Push start mode. When pushed in, the bike can start by a throttle input. When it's up, the rider needs to set the bike in motion first by pushing it off, then apply the throttle. This is safer for a beginner.

4. Safety lock. Press down to allow throttle inputs. This avoids accidental twist of the throttle to set off the bike  
5. Twist the throttle and start making memories!



## SADDLEBACK


Quick starting guide




For more information and owner's manual:  
[www.GreengerPowerSports.com/support](http://www.GreengerPowerSports.com/support)  
or scan the QR code >>




# Set Up



Attach the front wheel. Use a 15mm wrench to tighten the axle bolts to 12.5 ft lbs (IMPORTANT- DO NOT OVER-TIGHTEN). An improperly installed front wheel may cause accidents and injuries.




Install handlebar. Use a 4mm Allen wrench tighten the 4 screws to 3.75 ft lbs (IMPORTANT- DO NOT OVER-TIGHTEN). The brake lever should be on the brake side of the bike.




Ensure the cable is securely connected before operation. A loose connection can result in faulty operation of bike.


# Preparation



Adjust seat height. Remove the latch screw to open the latch. Make adjustments. After adjustments, close the latch and put the screw back in. The latch might need to be rotated to get the right clamping power.



Inspect the brake to make sure it produces adequate stopping power. Adjust the cable tension and put the screw back in. The latch might need to be rotated to get the right clamping power.



Using the supplied charger to charge the battery. The battery can be charged on or off the bike. Using an unapproved charger might cause damage to the battery or even fire.